

C7 Corvette Map Light Tinting Instructions

Important Instructions, Please Read Before Installation:

CAUTION: DO NOT REMOVE THE LENS FROM THE MAP HOUSING!! You will have to drop part of the headliner to re-install the lens if you do!

Start by covering the mirror with a cloth or something to keep you from touching the Onstar emergency button and tilt the mirror out of the way.



Cut a section of tinting approximately 3"x 3". Enough tinting is supplied to do both sides twice in case you make mistakes so cut sections with this in mind. Remove the adhesive backing by biting a corner of the film with your teeth and separating it. Carefully lay the film over the light making sure the entire light is covered.



Start in the middle of the lens and work the film out toward the edges making sure to eliminate bubbles and wrinkles. It helps to lift the film with one hand and press the film outward with the other.



Work the tint into the edges of the lens around the front side of the lens first. Next move to the rear of the lens behind the button. Lift the tint while working it onto the lens behind and around the button. It's tough to get the back of the lens covered without 1 small crease but where it's at it doesn't show easily.



Using a new razor blade, very carefully trim the excess tint from the lens by cutting against the lens not the fabric headliner. Go slow and be careful. Use your fingernail to press the tint into the edges.



Trim around the button being very careful on the corners. Use your fingernails to press the tint into the crease.



Remove the tint from the button. If you have to re-do the tint, clean the adhesive residue with wax or grease remover or window cleaner before re-applying the tint. Go back and press the tint into the corners and creases one last time.

If you have any further questions you can call us at 888-737-8388

1210 N. Kraemer Blvd. Anaheim, CA 92806 / www.westcoastcorvette.com