



SALES • COMPLETE SERVICE • PARTS • TOLL FREE: 1.888.737.8388 • FAX: 1.714.630.1422

C7 Corvette License Plate LED Instructions

Important Instructions, Please Read Before Installation:



Start at the left side of each housing. Use a screwdriver or similar tool to pry the lens down then slide the right side out.



Hold the black connector then turn the housing counterclockwise and remove the factory bulb. It may be hot!



Turn on the running lights. Insert the led. If it doesn't light turn it 180 degrees and re-insert it. Use the same procedure for both license plate bulbs.



Insert the socket into the housing by aligning the tabs. Then turn the housing clockwise to lock it in place. Place the housing back into the opening clipping the right side in first then the left.



If you have any further questions you can call us at 888-737-8388
1210 N. Kraemer Blvd. Anaheim, CA 92806 / www.westcoastcorvette.com