



SALES • COMPLETE SERVICE • PARTS
TOLL FREE: 1.888.737.8388 • FAX: 1.714.630.1422

C5 Taillight Acrylic Blackout Kit

Important Instructions, Please Read Before Installation:

Tools needed:

T-15 Torx bit (you may be able to use a small flat head screwdriver if you don't have the Torx bit)

1. Remove Torx screws from each taillight (2) for each light.
2. Insert one side at a time (not both at once, it won't fit) It's a tight secure fit once in. They were designed to take up the entire space and not just cover the red lens.
3. Reuse the T-15 stock screws but be sure NOT to tighten too much or you may risk breaking the blackout.
1. Clean Reverse & 3rd brake light with glass cleaner or soap and water, let dry.
2. Remove red plastic film from each piece of the 3m tape, carefully line up and press to the light while applying firm pressure for about 10 seconds. Note: this is clear 3m tape so you won't see any tape outlines when you hit your brakes or use your reverse lights.
3. Wash hands and enjoy!

If you have any further questions you can call us at 888-737-8388

1210 N. Kraemer Blvd. Anaheim, CA 92806

www.westcoastcorvette.com

15138000 C5 BlackoutKit