



SALES • COMPLETE SERVICE • PARTS • TOLL FREE: 1.888.737.8388 • FAX: 1.714.630.1422

## 2006-2013 Z06 & Grand Sport Quick Release Front Plate Frame

### Important Instructions, Please Read Before Installation:

**Parts List:** Mounting bracket, Removable plate frame, 1/4" 20 x 1.5" Machine screw, 1/4" 20 Wing nut, 2 - 1/4" 20 x 5/8" Machine screws

**Tools needed:** 1/4" Drive nut driver handle, 7mm socket, Flat bladed screwdriver



**Installation:** Jack up car and place on jack stands in such a manner to gain easy access to the bottom of the front bumper. Refer to user's manual for correct jacking procedure.

With the 7mm socket and nut driver handle remove and save the 7mm screws that hold the lower air dam to the fascia at the three slots on the left (driver's) side of the car. Remove the 7mm screws on either side of the driver's side skid plate at the back of the fascia and pull the fascia down slightly to gain access to the top of the skid plate.

Using the 7mm screws mount the forward portion of the mounting bracket to the fascia behind the air dam but **do NOT tighten the screws** as you will need to adjust the mount left or right to get proper alignment.

Push the bracket up against the skid plate and insert the machine screw through the two slotted holes in the mount. Install the wing nut and hand tighten.

Replace the rear section of the fascia and install screws and tighten.

Insert frame through the lower air dam holes and into the mount bracket until it snaps in place. Noting where the alignment of the plate frame through the holes is equidistant from each side of the air dam holes, pull out the plate frame and tighten the front 7mm screws.

Lower car off jack stands.

Insert your license plate into the plate frame and install the 1/4" 20 x 5/8" screws into the lower two holes in the plate frame.

Installation is now complete.

**Use:** The plate frame is easily removable when appropriate, such as for car shows, photo shoots, and racing. Simply pull on the frame in a straight and forward motion and it will pop loose.

To replace the plate frame, insert the longer alignment pins in the lower connection point. Push the plate straight into the mounting bracket until all four pins are completely in. Verify this either by feel or visually. **Verification is important to prevent inadvertent loss of the plate frame.**