



SALES • COMPLETE SERVICE • PARTS • TOLL FREE: 1.888.737.8388 • FAX: 1.714.630.1422

C6 Rear Taillight Spear Instructions

Remove taillight housing.

Clean taillights thoroughly. Use supplied templates and use a few pieces of tape to hold in place. Templates are labeled 1, 2, & 3. Start with #1. This template has a cut out at the top, which will assure a level fit.

Peel and stick each Spear into place pressing firmly to make a good bond. Repeat this step on each of the taillights until all Spears are installed.

As with any other exterior chrome accessories, make sure to keep clean and free of contaminant's to avoid corrosion and void in warranty.

If you have questions feel free to call us at 888.737.8388